



- NOTES:
1. REMOVE ALL BURRS AND SHARP EDGES.
  2. TOUCH UP POWDER COAT WITH EPOXY PAINT AS REQUIRED.
  3. REFER TO DRAWING 49205-04 FOR LID BRACE INSTALLATION.

[illegible]